



Dirac Live for ARCAM Radia Series

Required materials:

- The USB microphone and USB cable supplied with your ARCAM product.
- A PC/Mac connected to the same local network with internet as your ARCAM product.

Optional materials:

- A third party USB microphone and USB cable - such as the miniDSP UMIK-1/2.
- A stand for the microphone you are using. The supplied puck microphone will fit onto a camera tri-pod.

Getting Started with Dirac Live:

- Download and install Dirac Live for your PC/Mac. Get your download from dirac.com/live/downloads
- Play some music through your speakers and make sure they are in their final positions in your room.
- Connect the USB microphone to your PC/Mac.
- Launch the Dirac Live software and select your ARCAM Radia series product to start the measurement process.
- Select the connected microphone - ensure any microphone built into the PC/Mac is not selected.
- Load the microphone calibration file for your microphone - the calibration file for the microphone supplied with your ARCAM Radia product is included in the download with this document.
- Follow the steps in Dirac Live to complete the correction.
- Feel free to try the Harman in-room target included with this download.
- Any Dirac filter exported to the product, is immediately active. You can switch between this filter, any existing filters, and turn it off in the **Audio** options.